



## EQUIPMENT

# ROTARY TOOLS & FOOT PEDALS

### 1 No off button — the pedal IS the switch

These tools have no power button. The foot pedal controls all power. Treat it as a live switch at all times.

### 2 Connect the pedal only when ready to work

Plug in the foot pedal only after your handpiece is fitted and you are seated and ready to begin.

### 3 Return the pedal to the locker after every use

Unplug and store the foot pedal in its designated locker immediately. Never leave it on the floor.

### 4 Hang the handpiece above the bench

After each use, hang the handpiece on its hook above the bench — keeps cords clear and the surface free for others.

### 5 Wear eye protection at all times

Flying debris from burrs and bits is a serious hazard. Safety glasses on whenever the tool is running.

▲ PEDAL UNPLUGGED · HANDPIECE HUNG · BENCH CLEAR



**JEWELRY & METAL ARTS**  
BELLINGHAM MAKERSPACE