

# How to Print from Dymo LabelWriter 450

1. Open Dymo Connect application
2. Click New, then click barcode template (Label type: Small Multipurpose Labels LW 1"x2 1/8")
3. Customize template where you want each element to go (maker name at top, barcode below, item name below with the price).
4. Change barcode type to code 39
5. Clear all placeholder text for all the elements.
6. Click on import data, choose the catalog.xlsx recent file.
7. Select what row you want to import.
8. Now on the template when you click on an element there will be a purple box, click it and select what data you want to import in the selected area.
9. Make any sizing adjustments and print

---

Revision #2

Created 6 April 2024 20:09:15 by David L

Updated 6 April 2024 20:13:31 by David L